Danfoss

Pressure switches and thermostats, type CAS

Description



CAS units are pressure-controlled switches. The position of the contacts depends on the pressure in the inlet connection and the set value. In the series, special attention has been given to meeting demands for The CAS series covers most outdoor as well as indoor application requirements. CAS pressure controls are suitable for use in alarm and regulation systems in factories, diesel plant, compressors, power stations and on board ship.

- a high level of enclosure
- low differential
- robust and compact construction
- resistance to shock and vibration.

Contents

| | Page |
|------------------------------------|------|
| CAS pressure switches, description | 1 |
| Approvals | 2 |
| Ship approvals | 2 |
| Survey | 2 |
| ISO 9001 quality approval | 2 |
| Ordering | 3 |
| Terminology | 3 |
| Technical data | 4 |
| Dimensions and weight | 4 |
| Installation | 5 |
| Function | 6 |
| Accessories | 7 |
| | |
| CAS thermostats, description | 8 |
| Approvals | 8 |
| Ship approvals | 8 |
| Technical data and ordering | 8 |
| Dimensions and weight | 9 |
| Accessories | 9 |
| Installation | |
| Function | |
| Electrical connection | |
| Examples | |
| Conversion table | |
| | |

| Data sheet | Pressure switches and thermostats, type CAS | |
|----------------|--|---|
| Approvals | CE-marked acc. to EN 60947-5-1 CCC, China Compulsory Certificate | |
| Ship approvals | American Bureau of Shipping, USA (excl. CAS 139) Lloyds Register of Shipping, UK Germanischer Lloyd, Germany Bureau Veritas, France Det Norske Veritas, Norway | Registro Italiano Navale, Italy RMRS, Maritime Register of Shipping, Russia Nippon Kaiji Kyokai, Japan |

Survey

Pressure switches, type CAS

| 110350 | ie switches | , туре САЗ | | | | | | |
|----------|----------------|---------------|----------------|---------------|-------|--------|-----------|---------|
| | | | | | | | Range | Туре |
| 0 | 10 | 20 | 30 | 40 | 50 | 60 bar | P bar | |
| Standar | rd pressure sv | vitches | | | | | | |
| | | | | | | | 0 - 3.5 | CAS 133 |
| | | | | | | | 0 - 10 | CAS 136 |
| | | | | | | | 0 - 18 | CAS 137 |
| | | | | | | | 10 - 35 | CAS 139 |
| Pressure | e switches for | r high pressu | re and strongl | y pulsating m | nedia | | | |
| | | | | | | | 1 - 10 | CAS 143 |
| | | | | | | | 4 - 40 | CAS 145 |
| | | | | | | | 6 - 60 | CAS 147 |
| Differen | ntial pressure | switches | | | | | | |
| | | | | | | | 0.2 - 2.5 | CAS 155 |
| | | | | | | | I | |

Thermostats, type CAS

| | Range | | | | | | | Туре |
|---|-------|----|----|-----|-----|----|----------|---------|
| 0 | 30 | 60 | 90 | 120 | 150 | °C | °C | |
| | | | | | | | 20 - 80 | CAS 178 |
| | | | | | | | 70 - 120 | CAS 180 |
| | | | | | | | 60 - 150 | CAS 181 |
| | | | | | | | | |

ISO 9001 quality approval



Danfoss A/S is certificated by BSI in accordance with international standard ISO 9001. This means that Danfoss fulfils the international standard in respect of product development, design, production and sale. BSI exercises continuous inspection to ensure that Danfoss observes the requirements of the standard and that Danfoss' own quality assurance system is maintained at the required level.

Dantoso

Data sheet

Pressure switches and thermostats, type CAS

Ordering

Preferred version

Standard pressure switches

When ordering, please state type and code no.

Pressure controls for high pressure and strongly pulsating media

Permissible

operating

pressure

(bar)

120

120

120

Permissible

operating

pressure for

low pressure

(bar)

 $0 \rightarrow 8$

Mechanical

differential

(bar)

 $0.2 \rightarrow 0.6$

 $0.8 \rightarrow 2.4$

 $1 \rightarrow 3$

Differential pressure switch type CAS Mechanical

differential

(bar)

0.1

Setting range p^e

(bar)

 $1 \rightarrow 10$

 $4 \rightarrow 40$

 $6 \rightarrow 60$

Setting

range p^e

(bar)

 $0.2 \rightarrow 2.5$



CAS 133, 135, 139

| Setting range p ^e | Mechanical differential | Permissible operating pressure | Max test pressure | Min. burst pressure | Pressure connection | Code no. | Туре |
|---------------------------------|----------------------------|--------------------------------------|----------------------|------------------------|------------------------|------------|---------|
| (bar) | (bar) | (bar) | (bar) | (bar) | | | |
| $0 \rightarrow 3.5$ | 0.1 | 10 | 10 | 40 | | 060-315066 | CAS 133 |
| $0 \rightarrow 10$ | 0.2 | 22 | 22 | 40 | C 1/ | 060-315166 | CAS 136 |
| $6 \rightarrow 18$ | 0.3 | 27 | 27 | 72 | G ¼ | 060-315266 | CAS 137 |
| $10 \rightarrow 35$ | 0.6 | 53 | 53 | 100 | | 060-315366 | CAS 139 |

Max test

pressure

(bar)

180

180

180

Max test

pressure

(bar)

22

Min. burst

pressure

(bar)

240

240

240

Min. burst

pressure

(bar)

42

Pressure

connection

G ¼

Pressure

connection

2 x G ¼

Code no.

060-316066

060-316166

060-316266

Code no.

060-313066

Type

CAS 143

CAS 145

CAS 147

Туре

CAS 155



CAS 143, 145, 147



CAS 155

Terminology

Range setting

The pressure range within which the unit will give a signal (contact changeover).

Differential The difference between make pressure and break pressure (see also page 6).

Permissible burst pressure The highest permanent or recurring pressure the unit can be loaded with.

Max. test pressure

The highest pressure the unit may be subjected to when, for example, testing the system for leakage. Therefore, this presure must not occur as a recurring system pressure.

Min. burst pressure

The pressure which the pressure-sensitive element will withstand without leaking.

Dantos

Pressure switches and thermostats, type CAS

Technical data

Switch

Microswitch with single pole changeover (SPDT)

Contact load Alternating current: 220 V, 0.1 A, AC-14 and AC-15 (inductive load)

Direct current: 125 V, 12 W DC-13 (inductive load)

Materials in contact with the medium

| CAS | Bellows: | Stainless steel, material no. |
|-----|-------------|-------------------------------|
| 133 | | 1.4306 (DIN 17440) |
| 136 | Pressure | |
| 137 | connection: | Brass material no. 2.0401 |
| 139 | | (DIN 17660) |
| CAS | Diaphragm | |
| 143 | connection: | Nickel plated brass CuZn |
| 145 | | 40 Ob3 ISO R 426 |
| 147 | | (DIN 17569) |
| 155 | Diaphragm: | Nitrile-butadien rubber |

Ambient temperature

CAS 133-139: -40 to +70°C CAS 143-155: -25 to +70°C Temperature of medium CAS 133-139: -40 to + 100°C CAS 143-155: -25 to + 100°C For water and seawater, max. 80 °C

Vibration resistance Vibration-stable in the range 2-30 Hz amplitude 1.1 mm and 30-100 Hz, 4 G.

Enclosure

IP 67 acc. to IEC 529 and DIN 40050. The pressure control housing is enamelled pressure die cast aluminium (GD-AISi 12). The cover is fastened by four screws which are anchored to prevent loss. The enclosure can be sealed with fuse wire.


Cable entry

Pg 13.5 for cable diametrers from 5 to 14 mm.

Identification

The type designation and code no. of the unit is stamped in the side of the housing.

Dimensions



ant

Installation

Installation

CAS pressure controls are fitted with a 3 mm steel mounting plate. The units should not be allowed to hang from the pressure connection.

Pressure connection

When fitting or removing pressure lines, the spanner flats on the pressure connection should be used to apply counter-torque.

Steam plant

To protect the pressure element from excessive heat, the insertion of a water-filled loop is recommended. The loop can, for example, be made of 10 mm copper tube as shown in fig. 1.

<image>Fig. 1

Water systems

Water in the pressure element is not harmful, but in case of frost a water-filled pressure element may burst. To prevent this happening, the pressure control can be allowed to operate on an air cushion.

Media resistance


Se table of materials in contact with the medium, page 4. If seawater is involved, types CAS 143, 145, 147 are recommended.

Pulsations

If the pressure medium is superimposed with severe pulsations, which occur in automatic sprinkler systems (fire protection), fuel systems for diesel motors (priming lines), and hydraulic systems (e.g. propeller systems), etc, types case 143, 145, 147 are recommended. The maximum permissible pulsation level for these types is 120 bar.

Setting


When the pressure control cover is removed, and the locking screw (3) is lossened, the range can be set with the spindle (1) while at the same time the scale (2) is being read.



Electrical connection

CAS pressure controls are fitted with a PG 13.5 screwed cable entry that is suitable for cable diameters from 5 to 13 mm.

Contact function is shown in fig. 3.



Pressure switches and thermostats, type CAS


Dantos

Function

a. CAS 155

Contacts 1-4 make and contacts 1-2 break when the differential pressure rises above the set range value. The contacts changeover to their initial position when the differential pressure again falls to the range value minus the differential (see fig. 4).


- I. Alarm for rising differential pressure given at the set range value.
- II. Alarm for falling differential pressure given at the set range value minus the differential.



b. All other CAS pressure controls

Contacts 1-2 make and contacts 1-4 break when the pressure falls under the set range value. The contacts changeover to their initial position when the pressure again rises to the set range value plus the differential (see fig. 5). I. Alarm for falling pressure given at the set range value.

II. Alarm for rising pressure given at the set range value plus the differential.



Example 1:

An alarm must be given when the lubrication oil pressure in a motor falls below 0.8 bar. Select CAS 133 (range 0 to 3.5 bar).

The minimum permissible lubricating oils pressure of 0.8 bar must be set using the range spindle. The differential is fixed at 0.1 bar, i.e. the alarm will not cut out before the pressure rises to 0.9 bar.

The switch break function is normally used for alarm purposes, i.e. the alarm must be connected to terminals 1 and 4.

Example 2:

When the differential pressure exceeds 1.3 bar a filter must be cleaned.

The maximum static pressure (LP) for the CAS 155 of 8 bar must not be exceeded.

The pressure control range spindle must be set at 1.3 bar.

The alarm must be connected to terminals 1 and 2 (alarm for broken circuit).

Danfoss

Accessories

| Part | | Description | Qty. | Code no. |
|-----------------------|-----------|--|------|------------|
| Connector with nipple | 0 000 000 | Pipe thread ISO 228/1, G 3/8 connector, nipple and AL washer (10 mm ext. 8 mm int. diam) for solering onto steel or copper tubing, steel span of jaws 22 | 5 | 017-436866 |
| Connector with nipple | 0 000 00 | G 3/8 connector, nipple and washer (10 mm ext./ 6.5 mm int. diam.) for welding, steel span of jaws 22 | 1 | 017-422966 |
| Reducer | 0 | Pipe thread ISO 228/1, G 3/8 x 7/16 - 20 UNF reducer, washer, brass span of jaws 22 | 5 | 017-420566 |
| Adaptor | 0 🐠 | Pipe thread ISO 228/1, G 3/8 x 1/8 - 27 NPT with copper washer brass span of jaws 22 | 1 | 060-333466 |
| Adaptor | M) 0 | Pipe thread ISO 228/1, G 3/8 A x 1/4 - 18 NPT with copper washer brass span of jaws 22 | 1 | 060-333566 |
| Adaptor | 0 | Pipe thread ISO 228/1, G 3/8 x 1/4 - 18 NPT with copper washer brass span of jaws 22 | 1 | 060-333666 |
| Adaptor | | 7/16 - 20UNF x R 3/8 (ISO 7/1) brass, span of jaws 19 | 1 | 060-324066 |
| | • | G 1/4 A x G 3/8 A | | 060-333266 |
| Nipple | | G 1/4 A x ext. M10 x 1 with washer | | 060-333866 |
| Damping coil | | Pipe thread ISO 228/1, damping coil with G 3/8 connector and 1.5 m copper capillary tube. Standard washers are supplied. | 1 | 060-104766 |
| Armoured damping coil | | Pipe thread ISO 228/1, damping coil with G 3/8 connector and 1 m copper capillary tube. Standard washers are supplied. | 1 | 060-333366 |

Pressure switches and thermostats, type CAS

Description

CAS thermostats are temperature-controlled switches. The position of the contacts depends on the temperature of the sensor and the set scale value. In this series, special attention has been given to meeting demands for a high level of enclosure, robust and compact construction, and resistance to shock and vibration. The CAS series covers most outdoor as well as indoor application requirements.

CAS thermostats are suitable for use in monitoring and alarm systems in factories, diesel plant, compressors, power stations and on board ship.

Technical data and ordering



CAS with remote sensor, armoured capillary tube

| When orde | When ordering, please state type and code number | | | | | | | | | | | |
|----------------------|---|----------------------------|---------------|--------|------|------------|--------------------------|------------|---------|--|--|--|
| Setting range | Mechanical differential adjustable / fixed | Max. sensor temperature | | sensor | also | | Capillary tube length | Code no. | Туре | | | |
| °C | °C | °C | | m | m | | m | | | | | |
| $20 \rightarrow 80$ | 2.0 | 130 | 65 75 110 160 | | 2 | 060L315166 | CAS 178 | | | | | |
| $70 \rightarrow 120$ | 2.0 | 220 | 65 75 110 160 | | | | 2 | 060L315366 | CAS 180 | | | |
| $60 \rightarrow 150$ | 2.0 | 250 | 65 | 75 | 110 | 160 | 2 | 060L315566 | CAS 181 | | | |

Switch Microswitch with single pole changeover (SPDT)

Contact load Alternating current: 220 V, ~0,1 A, AC-14 and AC-15 (inductive load)

Direct current 125 V, 12W DC-13 (inductive load)

Ambient temperature CAS 178,180 and 181: -25°C \rightarrow +70°C

Vibration resistance Vibration-stable in the range 2-30 Hz, amplitude 1,1 mm and 30-100 Hz, 4 G.

Approvals

Ship approvals

CE marked acc. to EN 60947-5-1 CCC, China Compulsory Certificate

American Bureau of Shipping, USA Bureau Veritas, France Det Norske Veritas, Norway Germanischer Lloyd, Germany Lloyd Register of Shipping, UK Nippon Kaiji Kyokai, Japan Registro Italiano Navale, Italy RMRS, Maritime Register of Shipping, Russia

Enclosure

IP 67 acc. to IEC 529 and DIN 40050. The thermostat housing is enamelled pressure die cast aluminium (GD-AISI 12). The cover is fastened by four screws which are anchored to prevent loss.

The enclosure can be sealed with fuse wire.

Cable entry Pg 13.5 for cable diameters from 5 to 14 mm.

Identification


The type designation and code no. of the unit is stamped in the side of the housing.

Danfoss

| Accessories: Sensor pockets for | Sensor | А | Thread | Code no. | Sensor pocket | А | Thread | Code no. |
|---------------------------------|--------|-----|---------------------|------------|---------------|-----|---------|------------|
| thermostats | pocket | mm | В | | - | mm | В | |
| | Brass | 65 | 1⁄2 NPT | 060L326566 | | | | |
| | Brass | 75 | 1/2 NPT | 060L326466 | Steel 18/8 | 75 | G ½ A | 060L326766 |
| | | 75 | G ½ A | 060L326266 | | | | |
| | | 75 | G ¾ A | 060L326666 | | | | |
| 0 | | 75 | G 1/2 A (ISO 228/1) | 060L328166 | | | | |
| <u>.</u> | Brass | 110 | 1⁄2 NPT | 060L328066 | Steel 18/8 | 110 | G ½ A | 060L326866 |
| - 208S | | 110 | G ½ A | 060L327166 | | 110 | 1/2 NPT | 060L327066 |
| | | 110 | G 1/2 A (ISO 228/1) | 060L340666 | | | | |
| | | 110 | G ¾ A (ISO 228/1) | 060L340366 | | | | |
| | Brass | 160 | G ½ A | 060L326366 | Steel 18/8 | 160 | G ½ A | 060L326966 |
| │ | | 160 | G ¾ A (ISO 228/1) | 060L340566 | | | | |
| M18x1.5 | Brass | 200 | G ½ A | 060L320666 | Steel 18/8 | 200 | G ½ A | 060L323766 |
| | | 200 | G 1/2 A (ISO 228/1) | 060L340866 | | 200 | G ¾ A | 060L324866 |
| | | 200 | G ¾ A (ISO 228/1) | 060L340266 | | | | |
| Note: all sensor pockets are | Brass | 250 | G ½ A | 060L325466 | | | | |
| supplied without gland nut, | Brass | 330 | G ½ A | 060L325566 | | | | |
| gaskets and washes | Brass | 400 | G ½ A | 060L325666 | | | | |

| Other Accessories | | Description | Qty./ unit | Code no. |
|---|----------------------|--|------------|------------|
| Clamping band | | For CAS thermostats with remote sensor (L = 392 mm) | 10 | 017-420466 |
| Heat conductive compound (Tube with 4.5 cm³) | Our service services | For CAS with sensor fitted in a sensor pocket. For filling sensor pocket to improve heat transfer between pocket and sensor. Application range for compound: -20 to +150 °C, momentarily up to 220°C | 1 | 041E0114 |

Dimensions and weight





Pressure switches and thermostats, type CAS

Installation

Location of unit: CAS thermostats are designed to withstand the shocks that occur, for example, in ships on compressors and in large machine installations. CAS thermostats are fitted with a base of 3 mm steel plate for fixing to bulkheads, etc.

Resistance to media Material specifications for sensor pockets.

Sensor pocket brass

The tube is made of Ms 72 to DIN 17660, the threaded portion of So Ms 58 Pb to DIN 17661.


Sensor pocket, stainless steel 18/8 Material designation 1.4305 to DIN 17440.

Sensor position

As far as possible the sensor should be positioned so that its longitudinal axis is at right angles to the direction flow. The active part of the sensor is \emptyset 13 mm \times 47.5 mm.


The medium

The fastest reaction is obtained from a medium having high specific heat and high thermal conductivity. It is therefore advantageous to use a medium that fulfils these conditions (provided there is a choice). The flow velocity of the medium is also of significance. (The optimum flow velocity for liquids is about 0.3 m/s). For permissible media pressure see fig. 1.



Setting

When the thermostat cover is removed, and the locking screw (3) fig. 2 is loosened, the range can be set with the spindle (1) while at the same time the scale (2) is being read.




Scale correction

The sensor on CAS thermostats contains an adsorption charge. Therefore function is not affected whether the sensor is placed warmer or colder than the remaining part of the thermostatic element (bellows and capillary tube).

However, such a charge is to some extent sensitive to changes in the temperature of bellows and capillary tube. Under normal conditions this is of no importance, but if the thermostat is to be used in extreme ambient temperatures there will be a scale deviation. The deviation can be compensated for as follows: Scale correction = $Z \times a$

Z can be found from fig. 3, while a is the correction factor from the table below. (See example, page 11).


| Туре | Regulation range °C | Correction factor a for thermostats |
|---------|---------------------------|---|
| CAS 178 | $20 \rightarrow 80$ | 2.5 |
| CAS 180 | $70 \rightarrow 120$ | 2.4 |
| CAS 181 | $60 \rightarrow 150$ | 3.7 |



Pressure switches and thermostats, type CAS

Electrical connection

CAS thermostats are fitted with a Pg 13.5 screwed cable entry suitable for cables from 5 to 14 mm. Contact function, see fig. 4.



Function

minus the differential

Differentials

The mechanical differential is the differential determined by the design of the thermostat. The thermal differential (operating differential) is the differential the system operates on.

The thermal differential is always greater than the mechanical differential and depends on three factors:

1) Medium flow velocity


2) Temperature change rate of the medium

3) Heat transmission to the sensor

Thermostat function

Contacts 1-4 make while contacts 1-2 break when the temperature rises above the scale setting.

The contacts changeover to their initial position when the temperature falls to the scale setting minus the differential. See fig. 5.



Example 1

Diesel engine with cooling water temperature of 85°C (normal). An alarm must be triggered if the cooling water temperature exceeds 95°C. Choose a CAS thermostat 180 (range +70 to 120°C). Main spindle setting: 95°C. The required alarm function is obtained by connecting to thermostat terminals 1-4.

Example 2

Find the necessary scale correction for a CAS 180. Set +95°C at +50°C ambient temperature.

The relative scale setting Z can be calculated from the following formula:

Setting value - min. scale value $\frac{1}{\text{max. scale value - min. scale value}} \times 100 = \%$

Relative scale setting: $95 - 70 \times 100 = 50\%$ 120 - 70

Factor for scale deviation Z fig. 3, $Z \cong 0.7$ Correction factor a, see table page 10, fig. 3 = 2.4. Scale correction = Z x a = 0.7 x 2.4 = 1.7°C CAS must be set at 95 + 1.7 = 96.7°C

Danfoss

Conversion table

| | Pascal | Pascal per | | Kilopound | Meter | Technical | Physical | Torr | Inches | Poundforce |
|----------------------|-------------------------|--------------------------|--------------------------|-----------------------|-----------------------|------------------------|--------------------------|-------------------------|--------------------------|------------------------|
| | (= Newton | square mm | | per square | water | atmosphere | atmosphere | (0°C) | Hg (0°C) | per square |
| | per square | | | metre | gauge | | | | | inch |
| | metre) | | | (mm H ₂ O) | | (kp/cm²) | | | | |
| | N/m²) | | | | | | | | | (lbf/in²) |
| | PA | N/mm ² | bar | kp/m ² | m H₂O | at | atm | mm Hg | | psi |
| 1 Pa | 1 | 10 ⁻⁶ | 10-5 | 0.1020 | $1.020 	imes 10^{-4}$ | $1.020 	imes 10^{-5}$ | 9.869 × 10 ⁻⁵ | 7.500 ×10 ⁻³ | 2.953 × 10 ⁻⁴ | $1.450 	imes 10^{-4}$ |
| 1 N/mm ² | 10 ⁶ | 1 | 10 | $1.020 	imes 10^5$ | 102.0 | 10.20 | 9.869 | 7.5 ×103 | 295.3 | 145.0 |
| 1 bar | 105 | 0.1 | 1 | 10.197 ×103 | 10.20 | 1.020 | 0.9869 | 750 | 29.53 | 14.50 |
| 1 kp/m ² | 9.80665 | 9.807 × 10 ⁻⁶ | 9.807 × 10 ⁻⁵ | 1 | 10 ⁻³ | 10-4 | 0.9678 ×10 ⁻⁴ | 0.07355 | 2.896×10^{-3} | 1.422×10^{-3} |
| 1 m H ₂ O | 9806.7 | $9.807 	imes 10^3$ | 0.09807 | 1000 | 1 | 0.1 | 0.09678 | 73.55 | 2.896 | 1.422 |
| 1 at | 98.066 ×103 | 0.09807 | 0.9807 | 10 ⁴ | 10 | 1 | 0.9678 | 735.5 | 28.96 | 14.22 |
| 1 atm | 101.325×10^{3} | 0.1013 | 1.013 | 10.333 ×103 | 10.33 | 1.033 | 1 | 760 | 29.92 | 14.70 |
| 1 mm Hg | 133.32 | 1.333 × 10 ⁻⁴ | 1.333 × 10 ⁻³ | 13.60 | 0.01360 | 1.360×10^{-3} | 1.315×10^{-3} | 1 | 0.03937 | $1.934 	imes 10^{-2}$ |
| 1 in Hg | 3387 | $3.387 	imes 10^{-3}$ | 0.03387 | 345.3 | 0.3453 | 0.03453 | 0.03342 | 25.4 | 1 | 0.4912 |
| 1 psi | 6895 | 6.895 × 10 ⁻³ | 0.06895 | 703.1 | 0.7031 | 0.07031 | 0.96804 | 51.71 | 2.036 | 1 |

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.